



Security+Plus®

Want Maximum Protection?

Choose Gold Preferred

98% of Security+Plus customers do!

Gold Preferred coverage delivers the ultimate peace-of-mind protection for your new or pre-owned Nissan.

The CPO/Certified Select Wrap upgrade offers the same coverage as Gold Preferred, too.

Unparalleled value from your Nissan dealer

www.nissanusa.com/Security+Plus

Component Coverage

VEHICLE SYSTEMS	Gold Pref & Wrap	Silver Pref	Powertrain Pref	CPO/Certified Select LW
Engine	428	319	259	167
Transmission/Transfer Case	445	377	348	341
Drive Axle (FWD/RWD/AWD)	110	104	102	98
Hybrid/Electric Vehicle	75	56	29	28
Brakes	111	59	21	0
Electrical	300	244	23	0
Fuel System	86	54	33	0
Steering	101	72	52	0
Suspension	123	70	66	0
Air Conditioning/Heater	131	84	20	0
Body & Interior	291	106	0	0
Advanced Driver Assistance Systems	50	31	0	0
Infotainment	72	70	0	0
TOTAL	2,320+	1,640+	950+	630+

ADVANCED DRIVER ASSISTANCE SYSTEMS

	CPO D Pref & Wrap	Silver Pref	Powertrain Pref	CPO/Certified Select
CONTROL ASSY-INTERCOM CRUISE CONTROL	18995			
CONTROL ASSY-WARNING SENS	25125			
SWITCH ASSY - BSW	25126			
ICC BRAKE HOLD RELAY	25184			
ICC STEERING SWITCH	25185			
ICC BRAKE SWITCH	25186			
SWITCH-STEERING WHEEL PRO PILOT	25560			
FRONT REAR SENSOR BUZZER	25560			
BUZZER-SONAR BUZZER	25560			
SONAR ROAD SENSOR	25965			
SWITCH-SENSOR OFF-PARKING(SONAR)	25988			
SONAR SWITCH ASSY	25989			
FRONT SONAR SENSOR	25993			
FRONT REAR SONAR SENSOR	25994			
REAR SONAR SENSOR NS	25996			
REAR SONAR FRONT SIDE	25998			
SENSOR-SONAR REAR SIDE	25999			
BUZZER ASSY-LKS / LDW	26349			
WARNING CHIME/BUZZER	26350			
ICC WARNING CHIME	26553			
REAR BSW BUZZER	26610			
CONTROL ASSY-BACKVIEW	28262			
CONT ASSY CAMERA	28262			
UNIT-CONTROL-HD MAP	28249			
CAMERA ASSY-SIDE VIEW	28418			
VEHICLE DATA TRANSMITTER ASSY	28420			
CONTROL UNIT-CHASSIS	28420			
ADAS CONTROLLER	28427			
BSW CONTROL ASSY	28428			
CONTROL MODULE - BUZZER/DRIVER ASSISTANT	28429			
SIDE OBSTACLE WARNING SENSOR	28430			
SENSOR UNIT-INTRUDE	28436			
SENSOR ASSY - DISTANCE, ICC	28437			
REAR DISTANCE SENSOR	28442			
CAMERA ASSY-BACK VIEW	28442			
CAMERA ASSY - LKS / LDW	28443			
CAMERA ASSY-MIRROR/SMART ROOM	28445			
REAR SONAR SENSOR BRACKET	28452			
CONTROL MODULE BSW	28456			
REAR VIEW CONTROL ASSY	28461			
SOLENOID VALVE ASSY-BACK VIEW CAMERA	28479			
CONTROL ASSY-CAN GATEWAY	28481			
SOLENOID VALVE ASSY - BACK VIEW CAMERA	28499			
CONTROL UNIT-SONAR SENSOR	28575			
TUBE ASSY - WASHER REAR VIEW CAMERA	28593			
REAR VIEW CAMERA	28641			
LANE KEEP CAMERA	28642			
SIDE OBSTACLE WARNING SENSOR ASSY	28640			
REAR VIEW CAMERA KT	AA158			

AIR CONDITIONER/HEATER

	CPO D Pref & Wrap	Silver Pref	Powertrain Pref	CPO/Certified Select
COMPRESSOR BOLT	17190			
CONDENSER UNIT HEATER	17190			
RESERVOIR TANK CAP HEATER	21712			
TEMPERATURE SENSOR	22656			
REAR HEATER CONTROL	25207			
BLOWER MOTOR RELAY	25208			
HEATER RELAY	25214			
A/C REAR HEATER	25218			
REAR HEATER AIR CONDITIONER	25225			
FAN MOTOR RELAY	25246			
MAX COOLD DOOR RELAY	25257			
REAR HEATER RELAY	25274			
RELAY - AFS	25295			
CONTROL-REAR HEATER, FRONT	25307			
HIGH VOLT UNIT	27020			
REAR HEATER CORE	27013			
REAR HEATER MOTOR	27014			
HEATER & A/C CONTROL	27030			
VACUUM SELECTOR VALVE	27031			
A/C CONTROL	27032			
CONTROL CABLE	27033			
A/C HARNESS	27038			
A/C SWITCH	27041			
BLOWER CASE/HOUSING	27065			
BLOWER MOTOR & FAN	27070			
HEATER CONNECTOR	27071			
HEATER SWITCH RESISTOR	27077			
VACUUM MOTOR	27084			
VACUUM TANK	27084			
VACUUM WATER COCK	27090			
VACUUM CHECK VALVE	27096			
HEATER CORE	27115			
HEATER COIL	27116			
CONTROL CABLE	27124			
MODE ACTUATOR ASSY	27161			
PTC HEATER ASSY	27163			
Pipe ASSY HEATER	27164			
BLOWER CONTROL AMPLIFIER	27150			
REAR HEATER RESISTOR	27178			
DEFROSTER HOSE	27181			
HEATER TUBE	27185			
THERMISTOR	27322			
AMPLIFIER-THERMO CONTROL	27330			
REAR BLOWER MOTOR	27375			
FAN IMPELLER	27383			
REAR BLOWER UNIT	27384			
EVAPORATOR	27410			
REAR A/C HIGH TUBE ASSY	27413			
REAR A/C LOW TUBE ASSY	27414			
CASE ASSY	27415			
REAR COOLING UNIT ASSY	27416			
AIR PURIFIER CONTROL	27427			
AIR PURIFIER ASSEMBLY	27428			
AIR PURIFIER COMP	27452			
DRAIN HOSE	27619			
EVAPORATOR	27621			
SWITCH-HIGH PRESSURE	27623			
EXPANSION VALVE	27625			
CONDENSER ASSY	27626			
RADIATOR FAN CONTROL AMP	27651			
ELECTRIC A/C UNIT	27655			
RECEIVER DRIER	27640			
LOW PRESSURE SWITCH	27648			
CONDENSOR	27650			
CONDENSOR FAN & MOTOR	27651			
CONDENSER HANDLE	27652			
SUCTION THROTTLE VALVE	27660			
SWITCH-REAR A/C	27665			
SIDE VENT DUCT	27670			
ACCELERATION CUT SWITCH	27671			
COOLER PIPE	27677			
CONTROL VALVE	27680			
VACUUM LOCK-OFF SWITCH	27685			
FLOOR DUCT SENSOR	27700			
VENTILATOR DUCT SENSOR	27701			
DEFROSTER NOZZLE SENSOR	27702			
SUNLOAD SENSOR	27705			
SENSOR GRILLE	27706			
AIR PURIFIER SENSOR	27708			
SENSOR-REFRIGERANT TEMP, COMPRESSURE DISCHARGE	27710			
VACUUM HOSE	27711			
SENSOR AIR TEMPRTH HEATER OUTLET	27712			
SENSOR-OPTICAL	27715			
FAN CONTROL AMPLIFIER	27717			
INTAKE SENSOR	27723			
ASPIRATOR	27726			
IN-VEHICLE SENSOR	27727			
DUCT - ASPERATOR	27728			
COMPRESSOR SHAFT SEAL	27745			
WATER TEMP SENSOR	27732			
BI-LEVEL MOTOR ACTUATOR	27736			
FEEDBACK RESISTOR (PBR)	27738			
AIR MIX DOOR ACTUATOR	27740			
DOUBLE SOLENOID VACUUM VALVE	27741			
WATER CONTROL CLUTCH	27742			
SNAP RING	27744			
ACTUATOR - DEFROSTER DOOR	27747			
ACTUATOR-DRIVER SIDE, AIR MIX DOOR	27748			
ACTUATOR-DRIVER SIDE, INTAKE DOOR	27749			
TRANSISOR-POWER	27750			
ASPIRATOR FAN	27752			
WATER RELEASE VALVE	27753			
SENSOR-AMBIENT AIR TEMP	27757			
AUTO TEMP CNTRL UNIT	27762			
UNIT-CONTROL-HEAT PUMP	27763			
SUNLOAD SENSOR AMPLIFIER	27764			
SHIFT ACTUATOR VALVE	27765			
REAR FLOOR HEATER DUCT	27912			
AUTO AIR CONTROL AMPLIFIER	28520			
MAGNETIC CLUTCH AMPLIFIER	28525			
SEAL-CONDENSER SIDE	91284			
VALVE-EXPANSION	92200			
SUPER HEAT SWITCH	92310			
THERMAL PROTECTOR	92316			
ACCELERATION/TIMER	92340			
SUPER HEAT TIMER	92340			
HOSE - HEATER, INLET	92401			
HOSE - FRONT HEATER	92420			
HOSE ASSY - REAR HEATER, INLET	92420			
REAR HEATER TUBE	92433			
HEAT EXCHANGER, HIGH	92440			
HEAT EXCHANGER	92446			
REAR COOLER PIPE (REAR)	92460			
REAR COOLER ASSY (FRONT)	92462			
REAR HIGH/LOW COOLER PIPE	92471			
LOW PRESSURE FLEXIBLE HOSE	92480			
HIGH PRESSURE FLEXIBLE HOSE	92516			
COMPRESSOR RPM SENSOR	92551			
C-SENSOR ASSY NS	98805			

BODY & INTERIOR

	CPO D Pref & Wrap	Silver Pref	Powertrain Pref	CPO/Certified Select
LOCK-LID-CHARGE PORT	25640			
LOCK ASSY - ECO MODE	25651			
SWITCH ASSY - AIR CONTROL, SEAT	25715			
BACK DOOR LOCK ACTUATOR	25189			
SUN ROOF SLIDE SWITCH	25191			
SUN ROOF RELAY	25192			
MIRROR HEATER RELAY	25200			
REAR WINDOW OPENER	25209			
REAR WINDOW STORAGE OPEN CANCEL	25211			
RELAY, TOP STYL, RR LOCK OPENER	25212			
RELAY, TRUNK LID OPENER	25213			
RELAY, TRUNK LID OPEN CANCEL	25221			
BODY SONIC RELAY	25248			
SWITCH - LMT, REAR HOOD	25256			
SWITCH - LMT, REAR HOOD	25257			
BACK DOOR HATCH OPENER SWITCH	25260			
STORAGE OPENER SWITCH	25283			
SWITCH - TRUNK OPENER CANCEL	25285			
SWITCH - ROOF OPENER	25465			
SWITCH-SEAT MEMORY	25491			
SWITCH-SEAT MEMORY CANCEL	25492			
SWITCH-SEAT MEMORY	25504			
PWR FOLD SEAT SWITCH NS	25502			
SPIRAL CABLE	25544			
REMOTE MIRROR SWITCH	25545			
SWITCH - 3RD SEAT RECLINING	25570			
SWITCH - LMT, REAR HOOD	25566			
SWITCH - LMT, REAR HOOD	25567			
BACK DOOR HATCH OPENER SWITCH	25583			
STORAGE OPENER SWITCH	25585			
SWITCH - TRUNK OPENER CANCEL	25585			
SWITCH - ROOF OPENER	25465			
SWITCH-SEAT MEMORY	25491			
SWITCH-SEAT MEMORY CANCEL	25492			
SWITCH-SEAT MEMORY	25504			
PWR FOLD SEAT SWITCH NS	25502			
SPIRAL CABLE	25544			
REMOTE MIRROR SWITCH	25545			
SWITCH - 3RD SEAT RECLINING	25570			
SWITCH - LMT, REAR HOOD	25566			
SWITCH - LMT, REAR HOOD	25567			
BACK DOOR HATCH OPENER SWITCH	25583			
STORAGE OPENER SWITCH	25585			
SWITCH - TRUNK OPENER CANCEL	25585			
SWITCH - ROOF OPENER	25465			
SWITCH-SEAT MEMORY	25491			
SWITCH-SEAT MEMORY CANCEL	25492			
SWITCH-SEAT MEMORY	25504			
PWR FOLD SEAT SWITCH NS	25502			
SPIRAL CABLE	25544			
REMOTE MIRROR SWITCH	25545			
SWITCH - 3RD SEAT RECLINING	25570			
SWITCH - LMT, REAR HOOD	25566			
SWITCH - LMT, REAR HOOD	25567			
BACK DOOR HATCH OPENER SWITCH	25583			
STORAGE OPENER SWITCH	25585			
SWITCH - TRUNK OPENER CANCEL	25585			
SWITCH - ROOF OPENER	25465			
SWITCH-SEAT MEMORY	25491			
SWITCH-SEAT MEMORY CANCEL	25492			
SWITCH-SEAT MEMORY	25504			
PWR FOLD SEAT SWITCH NS	25502			
SPIRAL CABLE	25544			
REMOTE MIRROR SWITCH	25545			
SWITCH - 3RD SEAT RECLINING	25570			
SWITCH - LMT, REAR HOOD	25566			
SWITCH - LMT, REAR HOOD	25567			
BACK DOOR HATCH OPENER SWITCH	25583			
STORAGE OPENER SWITCH	25585			
SWITCH - TRUNK OPENER CANCEL	25585			
SWITCH - ROOF OPENER	25465			
SWITCH-SEAT MEMORY	25491			
SWITCH-SEAT MEMORY CANCEL	25492			
SWITCH-SEAT MEMORY	25504			
PWR FOLD SEAT SWITCH NS	25502			
SPIRAL CABLE	25544			
REMOTE MIRROR SWITCH	25545			
SWITCH - 3RD SEAT RECLINING	25570			
SWITCH - LMT, REAR HOOD	25566			
SWITCH - LMT, REAR HOOD	25567			
BACK DOOR HATCH OPENER SWITCH	25583			
STORAGE OPENER SWITCH	25585			
SWITCH - TRUNK OPENER CANCEL	25585			
SWITCH - ROOF OPENER	25465			
SWITCH-SEAT MEMORY	25491			
SWITCH-SEAT MEMORY CANCEL	25492			
SWITCH-SEAT MEMORY	25504			
PWR FOLD SEAT SWITCH NS	25502			
SPIRAL CABLE	25544			
REMOTE MIRROR SWITCH	25545			
SWITCH - 3RD SEAT RECLINING	25570			
SWITCH - LMT, REAR HOOD	25566			
SWITCH - LMT, REAR HOOD	25567			
BACK DOOR HATCH OPENER SWITCH	25583			
STORAGE OPENER SWITCH	25585			
SWITCH - TRUNK OPENER CANCEL	25585			
SWITCH - ROOF OPENER	25465			
SWITCH-SEAT MEMORY	25491			
SWITCH-SEAT MEMORY CANCEL	25492			
SWITCH-SEAT MEMORY	25504			

ENGINE (cont.)

		COLD Pref & W/rop	SILVER Pref	POWERTRAIN Pref	CPD/Certified Select
SUB RADIATOR PIPES/HOSES	21504				
HEV UNIT WATER HOSE	21505				
PUMP HOSE ASSY	21507				
CONVERTER HOSE ASSY	21508				
RESERVOIR TANK	21510				
RESERVOIR TANK BRACKET	21511				
SUB RAD RESERVOIR TANK	21512				
PIPE ASSY-CONVERTER INLET	21513				
HOSE-CONVERTER OUTLET	21514				
RESERVOIR TANK HOSE	21515				
PIPE ASSY-CONVERTER INLET	21516				
PUMP HOSE ASSY	21517				
HOSE-UPPER, SUB RADIATOR	21525				
HOSE-LOWER, SUB RADIATOR	21526				
HOSE INVERTER OUTLET	21534				
PIPE-PUMP INLET	21537				
ELECTRIC WATER PUMP	21580				
MOTOR ASSY WATER PUMP	21581				
THERMO SWITCH	21595				
RADIATOR FAN MOTOR	21597				
TUBE ASSY	21620				
OIL COOLER PIPING	21636				
TRANSISTOR IGNITION UNIT	22026				
EGR WATER TEMP SENSOR	22120				
VACUUM GALLERY	22310				
VIAS VENT HOSE	22320				
HOSE - VACUUM	22321				
SENSOR-TEMPERATURE,CHARGE AIR COOLER OUTLET PRESSURE	22350				
SENSOR-TEMPERATURE,CHARGE AIR COOLER OUTLET	22351				
BOOST SENSOR	22364				
EGR VACUUM CONTROL VALVE	22365				
ABSOLUTE PRESSURE SENSOR	22366				
IGNITION COIL/PWR TRANSISTOR	22433				
HIGH TENSION CABLE	22450				
RESISTOR	22460				
IGNITION COIL PROTECTOR	22465				
AIR CUT VALVE	22622				
SCV SENSOR ASSY	22623				
FR EXHAUST TEMP GAS SENSOR	22624				
FUEL TEMP SENSOR	22629				
TANK FUEL TEMPERATURE SENSOR	22634				
FUEL DAMPER	22675				
AIR FUEL RATIO SENSOR	22689				
ECC MAIN RELAY	22698				
DROPPING RESISTOR	22699				
ALTERNATOR	23100				
ALTERNATOR ROTOR	23108				
ALTERNATOR BEARING	23120				
ALTERNATOR BRUSH & HOLDER	23133				
ALTERNATOR PULLEY	23150				
IC VOLTAGE REGULATOR	23215				
STARTER MOTOR ASSY	23300				
FIELD COIL	23306				
ARMATURE	23310				
CLUTCH PINION	23312				
REDUCTION GEAR	23313				
STARTER SOLENOID	23343				
BRUSH	23380				
CRANKSHAFT POS. SENSOR (OBD POS)	23731				
CRANKSHAFT POS. SENSOR (REF)	23732				
SENSOR-IDLE STOP	23737				
VVL ACTUATOR ASSY	23745				
IVTC POSITION SENSOR NS	23750				
MOTOR ASSY - ACTUATOR	23753				
CONTROL UNIT-ELECTRIC VALVE TIMING	23754				
VTC-ELECTRIC	23756				
VTC ASSY-ELECTRIC	23757				
MODULE-VCR CONTROL	23780				
VTC SOLENOID ASSY	23796				
ENGINE SUB HARNESS	24079				
BATTERY VENT TUBE	24413				
BATTERY VENT TUBE	24414				
BATTERY FRAME/TRAV/ROD	24428				
EGR CONTROL UNIT	25024				
FUEL TANK SENSOR	25060				
COOLANT TEMP SENSOR	25080				
SENSOR-WATER LEVEL	25083				
EVAP CONTROL, SYST PRESS SENSOR	25086				
RADIATOR FAN RELAY	25217				
OIL PRESSURE SENDING UNIT	25240				
OIL PRESSURE SWITCH	25244				
COOLING FAN CONTROL	25305				
EGR RESERVOIR TANK	27085				
221-WATER CONTROL COCK	27117				
FLYWHEEL HOUSING NS	32040				
ELECTRO HYDRAULIC CNT	32085				
PLUG ASSY-DRAIN	32101				
PLUG ASSY-DRAIN	32111				
PRESSURE TUBE	46455				
QUICK CONNECTOR ASSY AIR PRESSURE TUBE	45456				
SENSOR-TURBOCHARGER SPEED	59126				
BRACKET ASSY-CHARGE PORT	62551				
ENGINE MOUNTING BRACKET	75117				
ADAPTER-FILTER HEAD	78323				
VACUUM HOSE	90004				
VALVE ASSY WATER	92231				
TUBE-BOOST SENSOR	97195				
INSULATOR-INTAKE PORT	11020				
INSULATOR-REAR MOTOR MOUNT, FRONT	11211				
SENSOR ASSY - TURBO SPEED	14443				
TURBO MOUNTING KIT, REMAN	14401				

FUEL SYSTEM

FAST FLOW CONTROL UNIT	11067				
VALVE ASSY - INTAKE BYPASS	14466				
HOSE - AIR, SUCTION	14468				
POWER VALVE SOLENOID VALVE ASSY	14517				
VACUUM PUMP ASSY	14650				
EXHAUST TEMP SENSOR	14730				
BPT VALVE	14741				
A.I.V. UNIT CASE	14810				
PUMP ASSY-AIR	14812				
A.I.V. TUBE	14821				
AIR INJECTION PIPE	14823				
VALVE ASSY-AIR CUT SOLENOID	14830				
AIR CONTROL VALVE	14832				
A.B. VALVE	14835				
AIR INJECTION VALVE	14854				
HOSE ASSY-AIR	14858				
EC-HOSE	14860				
CONNECTOR-HOSE,3WAY	14870				
CONNECTOR-HOSE	14879				
A.I.V. BOX	14880				
TUBE-EVAP CONTROL	14912				
SERVICE PORT-EVAP	14939				
ASSY-PURGE PUMP	14941				
SCV SOLENOID VALVE	14951				
POWER VALVE SOLENOID	14952				
SOLENOID VALVE ASSY	14955				
PURGE CONTROL	14956				
EVAP VACUUM TANK	14958				
EVAP CANISTER VENT	14960				
THROTTLE CHAMBER	16118				
PROTECTOR-FUEL,RAIL,LD-INJ HIGH PRESSURE	16265				
FUEL PUMP ASSY - HIGH PRESSURE	16630				
INSULATOR-FUEL,PUMP,HIGH PRESSURE	16634				
FUEL PRESSURE SENSOR	16637				
FUEL PUMP - IN TANK	17040				
FUEL CONNECTOR	17103				
THROTTLE CHAMBER	17118				
FUEL TANK	17201				
TUBE ASSY FILLER	17220				
FUEL FILLER NECK	17222				
FUEL FILLER CAP	17251				
FUEL CHECK VALVE	17330				
TUBE ASSY - FUEL FEED	17502				
PROTECTOR-FUEL, RAIL	17524				
UREA FILLER TUBE ASSY	20421				
UREA FILLER HOSE ASSY	20424				
UREA FLUID PUMP ASSY	20440				
UREA TANK CONTROLLER ASSY	20443				
UREA TANK CONTROLLER HARNESS	20458				
WATER HOSE ASSY - INLET, AIR COOLER	21518				
WATER HOSE ASSY - OUTLET, AIR COOLER	21520				
DETONATION SENSOR	22040				
VACUUM TANK	22327				
VIAS VACUUM TANK ASSY	22328				
CK SWITCH-CANISTER VAC CNTRL	22360				
VACUUM SWITCH	22361				
CONTROL UNIT - EFI	22611				
BRACKET-ECM	22612				
THROTTLE VALVE SWITCH	22620				
EXHAUST GAS TEMP SENSOR	22630				
AIR TEMPERATURE SENSOR	22631				
CYLINDER HEAD TEMP SENSOR	22632				
SENSOR-EXHAUST GAS TEMPERATURE	22640				
AIR REGULATOR	22660				
PRESSURE REGULATOR	22670				
PRESSURE REG. CONTROL MODULE	22671				
AIR FLOW METER	22680				
AIR FLOW METER BRACKET	22682				
VACUUM CONTROL VALVE	22686				
O2 SENSOR	22690				
REAR OXYGEN O2 SENSOR	22691				
DROPPING RESISTOR	22695				
MAIN & FUEL PUMP RELAY	22697				
SENSOR ASSY - DPF PRESSURE	22770				
SENSOR ASSY - NOX	22790				
CRANK ANGLE SENSOR	23730				
CRANK POSITION SENSOR-RING GEAR	23733				
A.A.C. VALVE	23781				
EFI HARNESS	24011				
SOLENOID-COMPRESSOR BYPASS VALVE	25679				
BASE ASSY-FUEL FILLER	78120				
FUELING STOPPER ASSY	78402				
HOUSING-STAGE2,FUEL FILTER	78507				
HOUSING-FUEL FILTER	78509				
SENSOR ASSY - DPF PM, REAR	22743				

HYBRID / ELECTRIC

INVERTER O-RING	14457				
REAR AIR GUIDE ASSY-AIR COOLER COOLING RADIATOR	21463				
AIR GUIDE ASSY-SUB RADIATOR	21464				
BRUSH-EARTH	23390				
HYBRID VEH CNTRL, (ECU)	23700				
EV DRIVE MOTOR CONTROL MODULE	23740				
INVERTER CONTROL ASSY	25333				
INVERTER CONTROL UNIT	25334				
CONTROL ASSY-STARTUP SOUND	28150				
TRACTION MOTOR ASSY	29000				
BRUSH ASSY	29017				
MOTOR ASSY-DRIVE,REAR	29020				
INVERTER (PCU)	29100				
INVERTER COMPL-POWER HEAD	29101				
HOUSING ASSY-CONNECTOR	29110				
INVERTER ASSY	29111				
HARNESS ASSY-HIGH VOLTAGE	29115				
INVERTER COVER BRACKET	29153				
BOX ASSY-DC/DC	29201				
POWER CONVERTER BOX ASSY	29202				
CONVERTER ASSY	29210				
COVER-PDM	29230				
BATTERY CONTROLLER ASSY	29300				
BATTERY CONTROL ASSY	29310				
JUNCTION NO2 BOX ASSY	29401				
JUNCTION BOX ASSY	29410				
BATTERY COOLING FAN	29500				
BUS BAR REAR MODULE	29501				
SENSOR ASSY-BATTERY	29502				
BATTERY SENSOR ASSY	29504				
BUS BAR LH MODULE	29505				
BUS BAR MAIN RH MODULE	29506				
BATTERY COOLER	29512				
BATTERY CONNECTOR BASE	29531				
CHARGER ASSY-BATTERY	29610				
BATTERY CHARGE PORT UNIT	29612				
CELL MODULE SOLAR	29620				
EVSE PACKAGE	29621				
INSULATOR	29640				
SWITCH - DISCONNECT SERVICE	29701				
CABLE POWER CONV TO LI-ION PACK	29702				
CABLE PWR CONV TO LI-HON PAK	29703				
CABLE (ON BOARD CHARGER TO DC/DC-I/B)	29707				
SW-DISCONNECT SERVICE	29711				
BATTERY UPPER COOLING DUCT	29714				
BATTERY SIDE COOLING DUCT	29715				
BATTERY SIDE COOLING DUCT	29716				
BATTERY SIDE COOLING DUCT	29717				
BRUSH AXLE ASSY	30051				
TRNSAXLE & MOTOR GENERATOR	31021				
OIL PUMP & MOTOR ASSY	31337				
LEVER	31965				
MANUAL TRANSMISSION ASSY / REDUCER	32010				
BATTERY FAN INLET DUCT	96712				
BATTERY COOLING DUCT INLET	96713				
WATER TUBE ASSY-FLOOR,REAR	21630				
WATER HOSE- DRIVE MOTOR,REAR	21531				
WATER HOSE-TRACTION MOTOR,REAR	21555				
WATER HOSE-TRACTION MOTOR, CENTER	21557				
WATER HOSE-TRACTION MOTOR FRONT	21558				
WATER TUBE-TRACTION MOTOR REAR	21559				
WATER TUBE-TRACTION MOTOR CENTER	21559				

INFOTAINMENT

WATER TUBE-TRACTION MOTOR FRONT	21560				
EV CONTROL BRACKET	23701				
GASKET	29049				
TRACTION MOTOR TERMINAL COVER	29075				
BRUSH-EARTH	29077				
TRACTION MOTOR ASSY-WATER INLET	29075				
O-RING SEAL	29076				
POWER HEAD INVERTER SEAL	29140				
GUSSET	291C1				
INVERTER COVER	291X2				
POWER CONVERTER BOX ASSY	292A2				
POWER DELIVERY MODULE	292C0				
CABLE ASSY INTJCN TO PWR HEAD	297A0				

STEERING

CELL PHONE SWITCH	18931				
REAR WINDOW ANTENNA AMP	25190				
RELAY-AUDIO AMP	25198				
NAVI SPEAKER RELAY	25273				
CONTROL ASSY-T MASTER	25914				
NAVI GPS ANTENNA ASSY	25957				
AUX JACK-AUDIO	26823				
CABLE-GPS ANTENNA FEEDER	27531				
SPEAKER	27933				
CABLE-AUX AUDIO SYSTEM	27960				
ANTENNA	27964				
CONDENSER	27984				
RADIO FINISHER	28011				
TUNER ASSY - AV	28050				
PRE-AMP SPEAKER AMP	28060				
REAR AMPLIFIER	28063				
POWER SUPPLY BOX	28089				
VIDEO OR NAVI DISPLAY ASSY	28090				
FES Video Monitor	28091				
DISPLAY MOTOR ASSY	28092				
DISPLAY ASSY-INTEGRATED	28094				
CABLE-LVDS AUDIO SYSTEM	28096				
DVD UNIT	28113				
SWITCH ASSY-DISK EJECT	28129				
TWEETER-RR DOOR	28184				
CHANGER-CD AUTO	28188				
TELEPHONE ANTENNA SET	28201				
ANT ASSY-SAT	28208				
ANTENNA ROD/MAST	28215				