



Gold Preferred coverage delivered

The CPO/Certified Select Wrap upgrade offers

⌂ Wrap
Pref Select
⌂ Wrap

ADVANCED DRIVER ASSISTANCE SYSTEMS		GOLD P	SILVER	POWERTRON CPO/Cert	GOLD P
CONTROL ASSY-INTELLIGENT CRUISE CONTROL	18995				
3RD SEAT MTR DRIVESHAFT	86913				

ADVANCED DRIVER ASSISTANCE SYSTEMS

[illegible][illegible]

ENGINE (cont.)

SUB RADIATOR PIPES/HOSES	21504				
HEV UNIT WATER HOSE	21505				
PUMP HOSE ASSY	21507				
CONVERTER HOSE ASSY	21508				
RESERVOIR TANK	21510				
RESERVOIR TANK BRACKET	21511				
SUB RAD RESERVOIR TANK	21512				
PIPE ASSY- CONVERTER INLET	21513				
HOSE-CONVERTER OUTLET	21514				
RESERVOIR TANK HOSE	21515				
PIPE ASSY-CONVERTER INLET	21516				
PUMP HOSE ASSY	21517				
HOSE-UPPER, SUB RADIATOR	21525				
HOSE-LOWER, SUB RADIATOR	21526				
HOSE-INVERTER OUTLET	21534				
PIPE-PUMP INLET	21537				
ELECTRIC WATER PUMP	21580				
MOTOR ASSY WATER PUMP	21581				
THERMO SWITCH	21595				
RADIATOR FAN MOTOR	21597				
TUBE ASSY	21620				
OIL COOLER PIPING	21636				
TRANSISTOR IGNITION UNIT	22020				
EGR WATER TEMP SENSOR	22120				
VACUUM GALLERY	22310				
VIA5 VENT HOSE	22320				
HOSE - VACUUM	22321				
SENSOR-TEMPERATURE,CHARGE AIR COOLER OUTLET PRESSURE	22350				
SENSOR-TEMPERATURE,CHARGE AIR COOLER OUTLET	22351				
BOOST SENSOR	22364				
EGR VACUUM CONTROL VALVE	22365				
ABSOLUTE PRESSURE SENSOR	22366				
IGNITION COIL/PWR TRANSISTOR	22433				
HIGH TENSION COIL	22450				
RESISTOR	22460				
IGNITION COIL PROTECTOR	22465				
AIR CUT VALVE	22622				
SCV SENSOR ASST	22623				
FR EXHAUST TEMP GAS SENSOR	22624				
FUEL TEMP SENSOR	22629				
TANK FUEL TEMPERATURE SENSOR	22634				
FUEL DAMPER	22675				
AIR FUEL RATIO SENSOR	22689				
ECC MAIN RELAY	22696				
DROPPING RESISTOR	22698				
ALTERNATOR	23100				
ALTERNATOR ROTOR	23108				
ALTERNATOR BEARING	23120				
ALTERNATOR BRUSH & HOLDER	23133				
ALTERNATOR PULLEY	23150				
IC VOLTAGE REGULATOR	23215				
STARTER MOTOR ASSY	23300				
FIELD COIL	23306				
ARMATURE	23310				
CLUTCH PINION	23312				
REDUCTION GEAR	23313				
STARTER SOLENOID	23343				
BRUSH	23380				
CRANKSHAFT POS. SENSOR (OBD POS)	23731				
CRANKSHAFT POS. SENSOR (REF)	23732				
SENSOR-IDLE STOP	23737				
VVL ACTUATOR ASSY	23745				
IVTC POSITION SENSOR NS	23750				
MOTOR ASSY - ACTUATOR	23753				
CONTROL UNIT-ELECTRIC VALVE TIMING	23754				
VTC-ELECTRIC	23756				
VTC ASSY-ELECTRIC	23757				
MODULE-VCR CONTROL	23780				
VTC SOLENOID ASSY	23796				
ENGINE SUB HARNESS	24079				
BATTERY VENT TUBE	24413				
BATTERY VENT TUBE	24414				
BATTERY FRAME/TRAY/ROD	24428				
EGR CONTROL UNIT	25024				
FUEL TANK SENSOR	25060				
COOLANT TEMP SENSOR	25080				
SENSOR-WATER LEVEL	25083				
EVAP CONTROL, SYST PRESS SENSOR	25086				
RADIATOR FAN RELAY	25217				
OIL PRESSURE SENDING UNIT	25240				
OIL PRESSURE SWITCH	25244				
COOLING FAN CONTROL	25305				
EGR RESERVOIR TANK	27085				
221-WATER CONTROL COCK	27117				
FLYWHEEL HOUSING NS	32040				
ELECTRO HYDRAULIC CNT	32085				
PLUG ASSY-DRAIN	32101				
PLUG ASSY-DRAIN	32111				
PRESSURE TUBE	45455				
QUICK CONNECTOR ASSY AIR PRESSURE TUBE	45456				
SENSOR-TURBOCHARGER SPEED	59126				
BRACKET ASSY-CHARGE PORT	62551				
ENGINE MOUNTING BRACKET	75117				
ADAPTER-FILTER HEAD	78323				
VACUUM HOSE	90004				
VALVE ASSY WATER	92231				
TUBE-BOOST SENSOR	97195				
INSULATOR-INTAKE PORT	11000				
INSULATOR-REAR MOTOR MOUNT, FRONT	11211				
SENSOR ASSY - TURBO SPEED	14443				
TURBO MOUNTING KIT, REMAN	14401				

FUEL SYSTEM

FAST CLOW CONTROL UNIT	11067				
VALVE ASSY - INTAKE BYPASS	14466				
HOSE - AIR, SUCTION	14468				
POWER VALVE SOLENOID VALVE ASSY	14517				
VACUUM PUMP ASSY	14650				
EXHAUST TEMP SENSOR	14730				
BPT VALVE	14741				
A.I.V. UNIT CASE	14810				
PUMP ASSY-AIR	14812				
A.I.V. TUBE	14821				
AIR INJECTION PIPE	14823				
VALVE ASSY-AIR CUT SOLENOID	14830				
AIR CONTROL VALVE	14832				
A.B. VALVE	14835				
AIR INJECTION VALVE	14854				
HOSE ASSY-AIR	14858				
EC-HOSE	14860				
CONNECTOR-HOSE-3WAY	14877				
CONNECTOR-HOSE	14879				
A.I.V. BOX	14880				
TUBE-EVAP CONTROL	14912				
SERVICE PORT-EVAP	14939				
ASSY-PURGE PUMP	14941				
SCV SOLENOID VALVE	14951				
POWER VALVE SOLENOID	14952				
SOLENOID VALVE ASSY	14955				
PURGE CONTROL	14956				
EVAP VACUUM TANK	14958				
EVAP CANISTER VENT	14960				
THROTTLE CHAMBER	16118				
PROTECTOR-FUEL RAIL,LD-INJ HIGH PRESSURE	16265				
FUEL PUMP ASSY - HIGH PRESSURE	16630				
INSULATOR-FUEL PUMPHIGH PRESSURE	16634				
FUEL PRESSURE SENSOR	16637				
FUEL PUMP - IN TANK	17040				
FUEL CONNECTOR	17103				
THROTTLE CHAMBER	17118				
FUEL TANK	17201				
TUBE ASSY FILLER	17220				
FUEL FILLER NECK	17222				
FUEL FILLER CAP	17251				
FUEL CHECK VALVE	17330				
TUBE ASSY - FUEL FEED	17502				
PROTECTOR-FUEL RAIL	17524				
UREA FILLER TUBE ASSY	20421				
UREA FILLER HOSE ASSY	20424				
UREA FLUID PUMP ASSY	20440				
UREA TANK CONTROLLER ASSY	20443				
UREA TANK CONTROLLER HARNESS	20458				
WATER HOSE ASSY - INLET, AIR COOLER	21518				
WATER HOSE ASSY - OUTLET, AIR COOLER	21520				
DETONATION SENSOR	22060				
VACUUM TANK	22327				
VIA5 VACUUM TANK ASSY	22328				
CK SWITCH-CANISTER VAC CNTRL	22360				
VACUUM SWITCH	22361				
CONTROL UNIT - EFI	22611				
BRACKET-ECM	22612				
THROTTLE VALVE SWITCH	22620				
EXHAUST GAS TEMP SENSOR	22630				
AIR TEMPERATURE SENSOR	22631				
CYLINDER HEAD TEMP SENSOR	22632				
SENSOR-EXHAUST GAS TEMPERATURE	22640				
AIR REGULATOR	22660				
PRESSURE REGULATOR	22670				
PRESSURE REG. CONTROL MODULE	22671				
AIR FLOW METER	22680				
AIR FLOW METER BRACKET	22682				
VACUUM CONTROL VALVE	22686				
O2 SENSOR	22690				
REAR OXYGEN O2 SENSOR	22691				
DROPPING RESISTOR	22695				
MAIN & FUEL PUMP RELAY	22697				
SENSOR ASSY - DPF PRESSURE	22770				
SENSOR ASSY - NOX	22790				
CRANK ANGLE SENSOR	23730				
CRANK POSITION SENSOR-RING GEAR	23733				
A.A.C. VALVE	23781				
EFI HARNESS	24011				
SOLENOID-COMPRESSOR BYPASS VALVE	25679				
BASE ASSY-FUEL FILLER	78120				
FUELING STOPPER ASSY	78402				
HOUSING-STAGE2,FUEL FILTER	78507				
HOUSING-FUEL FILTER	78509				
SENSOR ASSY - DPF PM, REAR	227A3				

HYBRID / ELECTRIC

INVERTER O-RING	14457				
REAR AIR GUIDE ASSY-AIR COOLER COOLING RADIATOR	21463				
AIR GUIDE ASSY-SUB RADIATOR	21464				
BRUSH-EARTH	23390				
HYBRID VEH CNTRL (ECU)	23700				
EV DRIVE MOTOR CONTROL MODULE	23740				
INVERTER CONTROL ASSY	25333				
INVERTER CONTROL UNIT	25334				
CONTROL ASSY-STARTUP SOUND	28150				
TRACTION MOTOR ASSY	29007				
BRUSH ASSY	29017				
MOTOR ASSY-DRIVE,REAR	29020				
INVERTER (PCU)	29100				
INVERTER COMPL-POWER HEAD	29101				
HOUSING ASSY-CONNECTOR	29110				
INVERTER ASSY	29111				
HARNESS ASSY-HIGH VOLTAGE	29115				
INVERTER COVER BRACKET	29153				
BOX ASSY-DC/DC	29201				
POWER CONVERTER BOX ASSY	29202				
CONVERTER ASSY	29210				
COVER-PDM	29230				
BATTERY CONTROLLER ASSY	29300				
BATTERY CONTROL ASSY	29310				
JUNCTION NO2 BOX ASSY	29340				
JUNCTION BOX ASSY	29410				
BATTERY COOLING FAN	29500				
BUS BAR REAR MODULE	29501				
SENSOR ASSY-BATTERY	29502				
BATTERY SENSOR ASSY	29504				
BUS BAR LH MODULE	29505				
BUS BAR MAIN RH MODULE	29506				
BATTERY COOLER	29512				
BATTERY CONNECTOR BASE	29531				
CHARGER ASSY-BATTERY	29610				
BATTERY CHARGE PORT UNIT	29612				
CELL MODULE SOLAR	29620				
EVSE PACKAGE	29621				
INVERTER	29640				
SWITCH - DISCONNECT SERVICE	29701				
CABLE POWER CONV TO LH-ON COMPRES	29702				
CABLE (ON BOARD CHARGER TO DC/DC-J/B)	29703				
SW-DISCONNECT SERVICE	29711				
BATTERY UPPER COOLING DUCT	29714				
BATTERY SIDE COOLING DUCT	29715				
BATTERY SIDE COOLG DUCT	29716				
BRUSH ASSY	30051				
TRANSAXLE & MOTOR GENERATOR	31021				
OIL PUMP & MOTOR ASSY	31367				
LEVER	31965				
MANUAL TRANSMISSION ASSY / REDUCER	32010				
BATTERY FAN INLET DUCT	96712				
BATTERY COOLING DUCT INLET	96713				
WATER TUBE ASSY- FLOOR,REAR	21530				
WATER HOSE- DRIVE MOTOR,REAR	21531				
WATER HOSE-TRACTION MOTOR REAR	21555				
WATER HOSE-TRACTION MOTOR CENTER	21556				
WATER HOSE-TRACTION MOTOR FRONT	21557				
WATER HOSE-TRACTION MOTOR REAR	21558				
WATER TUBE-TRACTION MOTOR CENTER	21559				

WATER TUBE-TRACTION MOTOR FRONT	21560				
EV CONTROL BRACKET	23701				
GASKET	29049				
TRACTION MOTOR TERMINAL COVER	29075				
BRUSH-EARTH	29077				
TRACTION MOTOR ASSY-WATER INLET	290Y5				
O-RING SEAL	290Y6				
POWER HEAD INVERTER SEAL	29101				
GUSSET	291C1				
INVERTER COVER	291X2				
POWER CONVERTER BOX ASSY	292A2				
POWER DELIVERY MODULE	292C0				
CABLE ASSY JNTCN TO PWR HEAD	297A0				

INFOTAINMENT

CELL PHONE SWITCH	18931				
REAR WINDOW ANTENNA AMP	25190				
RELAY-AUDIO AMP	25198				
NAVI SPEAKER RELAY	25273				
CONTROL ASSY-T MASTER	25914				
NAVI GPS ANTENNA ASSY	25957				
AUX JACK-AUDIO	26823				
CABLE-GPS ANTENNA FEEDER	27531				
SPEAKER	27933				
CABLE-AUX AUDIO SYSTEM	27946				
ANTENNA	27960				
CONDENSER	27984				
RADIO FINISHER	28041				
TUNER ASSY - AV	28050				
PRE-AMP SPEAKER AMP	28060				
REAR AMPLIFIER	28063				
POWER SUPPLY BOX	28089				
VIDEO OR NAVI DISPLAY ASSY	28090				
FES Video Monitor	28091				
DISPLAY MOTOR ASSY	28092				
DISLAY ASSY-INTEGRATED	28094				
CABLE-LVDS AUDIO SYSTEM	28096				
DVD UNIT	28119				
SWITCH ASSY-DISK EJECT	28123				
TWEETER-RR DOOR	28184				
CHANGER-CD AUTO	28184				
TELEPHONE ANTENNA SET	28201				
ANT ASSY-SAT	28208				
ANTENNA ROD/MAST	28215				
SAT ANTENNA ASSY	28228				
FEEDER ASSY - ANTENNA	28243				
FEEDER ASSY (TEL ADPTR/BLUE TOOTH)-ANT	28245				
ANTENNA-ADAPTOR	28247				
CONTROL PANEL-FES	28259				